



2. KJHTL75DT  
ENGINE



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
2-1	859792	Engine	1	HE230/34
2-2	283149	Cylinder	1	New gasket required
2-3	283177	Gasket	1	
2-4	267290	Cap Screw	2	M5X20WSW
2-5	265802	Insulator	1	New gasket required
2-6	267049	Gasket	1	
2-7	265924	Cap Screw	2	M5X25WSW
2-8	283166	Muffler Ass'y	1	
2-9	264223	Cap Screw	2	M5X40
2-10	283176	Gasket	1	
2-11	283175	Under Cover	1	
2-12	261607	Cap Screw	1	M5X16WSW
2-13	286388	Top Cover Ass'y	1	Incl.14-16
2-14	283161	Top Cover	1	
2-15	286399	Knob	1	M5
2-16	286270	Washer	1	M5
2-17	283150	Crankcase	1	
2-18	261181	Bearing	2	6000C3
2-19	262712	Oil Seal	1	
2-20	262713	Oil Seal	1	
2-21	054676	Snap Ring	1	#26
2-22	261246	Cap Screw	3	M5X25
2-23	283265	Piston	1	
2-24	263789	Piston Ring	1	
2-25	281185	Piston Pin	1	5.9X8X25.5L
2-26	261037	Bearing, Needle	1	
2-27	261576	Clip, Piston	2	
2-28	283155	Crankshaft/Conn.Rod Ass'y	1	
2-29	280404	Clutch Ass'y	1	Incl.30-32
2-30	280568	Clutch Shoe	2	(2)required
2-31	280569	Clutch Boss	1	
2-32	280570	Spring	2	(2)required
2-33	283160	Fan Cover	1	
2-34	261250	Cap Screw	3	M5X20
2-35	283163	Magneto Ass'y	1	Incl.36-44
2-36	283164	Rotor/Fan	1	
2-37	283165	Ignition Coil Ass'y	1	Incl.38-44
2-38	283267	Coil	1	
2-39	283268	Spark Plug Wire Ass'y	1	Incl.40-42
2-40	283269	Spark Plug Wire	1	
2-41	283178	Plug Boot	1	
2-42	272805	Connector	1	
2-43	283271	Cap	1	
2-44	283272	Insulator	1	
2-45	269722	Wire, Lead	1	


Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
2-46	261076	Woodruff Key	1	3X10
2-47	261077	Nut, Rotor	1	M6
2-48	280381	Spacer	2	
2-49	281211	Cap Screw	2	M4X20WSW
2-50	262483	Spark Plug	1	BPMR6Y
2-51	283140	Grommet	1	
2-52	283169	Recoil Starter Ass'y	1	Incl.53-66
2-53	283170	Recoil Ass'y	1	Incl.54-61
2-54	280492	Pulley	1	
2-55	287421	Spiral Spring	1	
2-56	280494	Screw	1	
2-57	280497	Starter Grip	1	
2-58	280550	Rope Stopper	1	
2-59	283616	Starter Rope	1	
2-60	280547	Washer	1	
2-61	280548	Collar	1	
2-62	280532	Starter Pawl Ass'y	1	Incl.63-66
2-63	280533	Pawl Case	1	
2-64	269699	Pawl	2	
2-65	280553	Return Spring	2	
2-66	020299	E-Ring	2	#4
2-67	280144	Screw	3	4X16
2-68	264535	Screw	2	M6X20
2-69	275742	Label	1	
2-70	266959	Label	1	

3. KJHTL75DT  
 CARBURETOR, FUEL TANK



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
3-1	283436	Carburetor Ass'y	1	Incl.2-15
3-2	268499	Pump Body	1	
3-3	262991	Purge Body	1	
3-4	262992	Cover Plate	1	
3-5	261874	Primer Bulb	1	
3-6	283905	Diaphragm, Meterring	1	
3-7	262993	Gasket	1	
3-8	262994	Diaphragm, Fuel Pump	1	
3-9	282576	Gasket	1	
3-10	289621	Main Jet	1	
3-11	261871	O-Ring	1	
3-12	261876	E-Ring	1	
3-13	261658	Swivel	1	
3-14	264682	Screw	2	
3-15	262996	Screw	4	
3-16	268535	Stay	1	
3-17	283181	Gasket	1	
3-18	264708	Cleaner Ass'y	1	Incl.19-21
3-19	264709	Cleaner Cover	1	
3-20	264693	Case Ass'y	1	
3-21	264695	Element	1	
3-22	268963	Gasket	1	19.4X14.8XT3.0
3-23	269834	Screw	2	M5X60WSW
3-24	283437	Fuel Tank Ass'y	1	Incl.25-35
3-25	283162	Fuel Tank	1	
3-26	283438	Tank Cap Ass'y	1	Incl.27,28
3-27	283727	Gasket	1	
3-28	283764	Breather Ass'y	1	
3-29	265752	Fuel Pipe Pick-up Ass'y	1	Incl.30-35
3-30	264031	Fuel Pipe Ass'y	1	Incl.31-33
3-31	261115	Grommet	1	
3-32	261690	Fuel Pipe	1	160L
3-33	263038	Return Pipe	1	3X6X85
3-34	264653	Filter Ass'y	1	
3-35	261117	Clip	1	
3-36	264318	Pad	2	
3-37	261118	Pad	2	
3-38	261117	Clip	1	





1. KJHTL75DT  
MAIN BODY



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
1-1	362399	KJHTL75DT	1	
1-2	276004	Guide Plate	1	
1-3	275789	Blade	2	
1-4	274877	Blade Guard	1	
1-5	991914	Screw	3	
1-6	271229	Screw	1	
1-7	991913	Washer	4	
1-8	991941	Nut	3	
1-9	270071	Cover of Blade	1	
1-10	271396	Rear Handle Ass'y	1	Incl.11-29
1-11	271278	Rear Handle (L)	1	
1-12	271279	Rear Handle (R)	1	
1-13	271280	Lever	1	
1-14	271281	Stop Lever	1	
1-15	271282	Lock Lever	1	
1-16	271283	Lock Lever Stopper	1	
1-17	271284	Rod	1	
1-18	271285	Switch	1	
1-19	271398	Cable Comp.	1	
1-20	271287	Spacer	1	
1-21	271288	Spring	1	
1-22	271289	Spring	1	
1-23	270400	Spring	1	
1-24	271276	Screw	5	
1-25	271274	Handle Stay (L)	1	
1-26	271275	Handle Stay (R)	1	
1-27	271276	Screw	3	
1-28	270424	Spacer	1	
1-29	271277	Spacer	2	
1-30	270241	Front Handle	1	
1-31	991941	Nut	2	
1-32	270566	Label	2	
1-33	271221	Tube	1	
1-34	271425	Screw	4	
1-35	270705	Screw	2	
1-36	271219	Screw	2	
1-37	271220	Screw	1	
1-38	270843	Washer	1	25X6XT1.6
1-39	271222	Upper Case	1	
1-40	271410	Pinion	1	
1-41	270021	Clutch Drum	1	
1-42	270423	Bearing	1	
1-43	580767	Bearing	1	
1-44	271230	Screw	2	
1-45	271231	Nut	2	

Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
1-46	991937	Grease Nipple	1	
1-47	271223	Lower Case	1	
1-48	271224	Plate	1	
1-49	991924	Screw	1	
1-50	270423	Bearing	2	
1-51	270552	Crank Comp.	1	
1-52	271225	Rod	2	
1-53	271227	Felt	1	
1-54	271895	Screw	1	
1-55	580791	Screw	6	
1-56	991941	Nut	1	
1-57	580777	Snap Ring	1	
1-58	266957	Label	1	
1-59	266960	Label	1	
1-60	283526	Label	1	

4. KJHTL75DT  
ACCESSORIES



Ref. No.	Parts No.	Parts Name	Q'ty	Remarks
4-1	275834	Instruction Manual	1	KJHTL75DT(FIABA)
4-2	275835	Instruction Manual	1	KJHTL75DT(FIABA)
4-3	524007	Parts List	1	KJHTL75DT/FIABA
4-4	264606	Tool Set	1	Incl.5-7
4-5	264607	Box Spanner	1	
4-6	219431	Wrench	1	3mm
4-7	219432	Wrench	1	4mm