




1. KJBL22E MAIN BODY




Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-1	364805	KJBL22E	1	
1-2	226546	Driveshaft Ass'y	1	
1-3	226544	Driveshaft Tube	1	
1-4	235078	Throttle Trigger	1	
1-5	215533	Hanging Bracket Ass'y	1	Incl.6
1-6	261762	Cap Screw	1	M5x14
1-7	241819	Label	1	KJBL22E
1-8	223188	Label	1	
1-9	228043	Label	1	
1-10	220533	Hanging Strap Ass'y	1	Incl.11
1-11	231657	Hook	1	
1-12	231955	Loop Handle Ass'y	1	Incl.13-15
1-13	225699	Loop Handle	1	
1-14	081027	Nut	4	M5
1-15	215608	Cap Screw	4	M5x30x16
1-16	235690	Safety Cover Ass'y	1	Incl.17-23
1-17	235691	Safety Cover Ass'y	1	Incl.18,19
1-18	227819	Bracket	1	
1-19	221580	Screw	1	4x8
1-20	232076	Bracket Ass'y	1	Incl.21-23
1-21	227820	Bracket	1	
1-22	220632	Cap Screw	2	M6x30
1-23	231704	Washer	2	6x13xt1.0
1-24	231882	String Cutter Ass'y	1	Incl.25-27
1-25	230747	String Cutter	1	
1-26	261250	Cap Screw	1	M5x20
1-27	228325	Nut	1	
1-28	231033	Cover Extention	1	

2. KJBL22E GEARCASE



Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	232070	Gearcase Ass'y	1	Incl.2-16
2-2	226284	Gearcase	1	
2-3	225897	Bolt	1	M6x8
2-4	226285	Bearing	1	#626
2-5	227108	Gear Set	1	
2-6	112184	Bearing	1	#6000DDU
2-7	054676	Snap Ring	1	#26
2-8	225898	Collar	1	10x16xt2.6
2-9	226286	Bearing	1	#609ZZ
2-10	228477	Snap Ring	1	#9
2-11	140270	Snap Ring	1	#24
2-12	261246	Cap Screw	1	M5x25
2-13	225891	Boss Adapter	1	
2-14	225892	Blade Boss B	1	
2-15	225893	Nut	1	M8
2-16	219087	Cap Screw	1	M5x10


3. KJBL22E ENGINE



Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-1	875307	Engine	1	EE232/04
3-2	289639	Cylinder	1	
3-3	289643	Gasket	1	
3-4	267290	Cap Screw	2	M5x20
3-5	272744	Insulator	1	New gasket required
3-6	267049	Gasket	1	
3-7	269826	Screw	2	M5x25
3-8	278096	Muffler Comp	1	
3-9	266402	Cap Screw	2	M5x55
3-10	273262	Gasket	1	
3-11	276868	Under Cover	1	
3-12	269827	Screw	1	M5x16
3-13	277673	Top Cover	1	
3-14	280144	Tapping Screw	1	
3-15	273674	Crankcase	1	
3-16	280488	Bearing	2	PPL 6001
3-17	261492	Oil Seal	1	ISCD12287
3-18	261386	Oil Seal	1	ISCD12227
3-19	055185	Snap Ring	1	H28
3-20	261612	Cap Screw	3	M5x30
3-21	272204	Piston	1	
3-22	264891	Piston Ring	2	(2)required
3-23	261036	Piston Pin	1	
3-24	288520	Bearing, Needle	1	
3-25	261576	Clip,Piston	2	
3-26	274146	Crankshaft/Conn.Rod Ass'y	1	
3-27	280375	Clutch Ass'y	1	Incl.28,29
3-28	280407	Clutch Shoe	2	
3-29	264889	Spring,Clutch	1	
3-30	264505	Bolt	2	
3-31	261777	Wave Washer	2	
3-32	261189	Washer	2	6x16.5x1.2
3-33	286528	Fan Cover	1	
3-34	280506	Fan Cover	1	
3-35	280314	Clutch Drum	1	
3-36	014210	Snap Ring	1	#10
3-37	269831	Screw	4	M5x20
3-38	269991	Cushion	1	
3-39	280477	Screw	1	M5x28
3-40	269423	Nut	1	
3-41	282403	Screw	1	M4x14
3-42	274927	Magneto Ass'y	1	Incl.43-49
3-43	283397	Rotor/Fan	1	
3-44	283165	Ignition Coil Ass'y	1	Incl.45-49
3-45	283268	Spark Plug Wire Ass'y	1	Incl.46,47


Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-46	283178	Plug Boot	1	3x10
3-47	272805	Connector	1	
3-48	283271	Cap	1	
3-49	283272	Insulator	1	
3-50	261076	Woodruff Key	1	
3-51	261417	Nut,Rotor	1	M8
3-52	280381	Spacer	2	M4x25 BPMR8Y
3-53	261256	Cap Screw	2	
3-54	288264	Spark Plug	1	
3-55	269722	Lead	1	KJ
3-56	282880	Wire, Lead	1	
3-57	280670	Grommet	1	
3-58	275051	Label	1	
3-59	284587	Label	1	

4. KJBL22E
RECOIL STARTER













Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-1	288684	Recoil Starter Ass'y	1	Incl.2-10
4-2	288685	Starter Ass'y	1	Incl.3-9
4-3	288967	Reel	1	
4-4	288968	Spiral Spring	1	
4-5	262922	Screw	1	
4-6	288969	Starter Rope Ass'y	1	Incl.7-9
4-7	288970	Starter Rope	1	
4-8	261725	Starter Grip	1	
4-9	283511	Rope Stopper	1	
4-10	288971	Starter Pawl Ass'y	1	
4-11	269833	Screw	1	M4x16
4-12	280489	Screw	2	M4x20
4-13	274246	Label	1	

5. KJBL22E
CARBURETOR, FUEL TANK



Ref. No.	Part No.	Part Name	Q'ty	Remarks
5-1	276663	Carburetor Ass'y	1	Incl.2-15 New gasket required
5-2	274472	Pump Body	1	
5-3	262991	Purge Body	1	
5-4	262992	Cover Plate	1	
5-5	261874	Primer Bulb	1	
5-6	283905	Diaphragm, Meterring	1	
5-7	262993	Gasket	1	
5-8	262994	Diaphragm,Fuel Pump	1	
5-9	282576	Gasket	1	
5-10	289396	Main Jet	1	
5-11	261871	O-Ring	1	Incl.19-21
5-12	261876	E-Ring	1	
5-13	261658	Swivel	1	
5-14	264682	Screw	2	
5-15	262996	Screw	4	
5-16	261864	Gasket	1	
5-17	264691	O-Ring	1	
5-18	277926	Cleaner Ass'y	1	
5-19	266433	Housing	1	
5-20	264695	Filter	1	
5-21	277554	Cover	1	Incl.24-34
5-22	269834	Screw	2	
5-23	276798	Fuel Tank Ass'y	1	
5-24	273516	Fuel Tank	1	
5-25	275306	Fuel Tank Cap Ass'y	1	
5-26	274875	Gasket	1	Incl.29-34
5-27	261696	Breather Ass'y	1	
5-28	265752	Fuel Pipe Pick-up Ass'y	1	
5-29	264031	Fuel Pipe Ass'y	1	
5-30	261115	Grommet	1	
5-31	261690	Fuel Pipe	1	160L
5-32	263038	Return Pipe	1	3x6x85L
5-33	264653	Filter Ass'y	1	
5-34	261117	Clip	1	
5-35	261117	Clip	1	
5-36	269828	Screw	2	M5x16
5-37	281208	Screw	1	M5x16

6. KJBL22E
ACCESSORIES



Ref. No.	Part No.	Part Name	Q'ty	Remarks
6-1	210418	Box Spanner	1	13x19x(+)
6-2	022865	Double-ended Wrench	1	8x10
6-3	219431	Wrench	1	3mm
6-4	219432	Wrench	1	4mm
6-5	219433	Wrench	1	5mm
6-6	232225	Semi-Auto Head (L)	1	
6-7	234954	Colgate Tube	1	60L
6-8	234955	Band	1	3.4x145L
6-9	241820	Instruction Manual	1	KJBL22-36E
6-10	524736	Parts List	1	KJBL22E