


POS.NR	PART NR.	DESCRIZIONE	DESCRIPTION	Q.TY	REMARK
1	436-42000	Motore NB430	ENGINE ASSY	1	
2	43-45300	Boccola	OIL BEARING	6	
3	32-45123	Asta esterna	ALUMINIUM PIPE	1	
4	32-45130	Asta interna	DRIVE SHAFT	1	
5	323-43030	Manubrio bike	BICYCLE HANDLE	1	
ZC1	323-47080	Comando acceleratore completo	BICYCLE HANDLE ASSY	1	
6	323-47081	Leva interruttore	PLATE-SWITCH	1	
7	323-47084	Carter sinistro	LEFT COVER FOR HANDLE	1	
8	YD25-92001	Vite	SCREW	1	
9	323-47086	Molla	SPRING OF LEVER-SAFETY TRIGGER	1	
10	323-47090	Cavo acceleratore/stop	WIRE ASSY	1	
11	323-47088	Leva di sicurezza	LEVER-SAFETY TRIGGER	1	
12	323-47083	Bilanciere interruttore	SWITCH REED	1	
13	323-47112	Molla	PRESSING CIRCLIP	1	
14	323-47113	Vite	SCREW	1	
15	323-47114	Inserto	CARD HOLDER	1	
15-1	323-47115	Profilo	CARD HOLDER REED	1	
16	323-47092	Molla acceleratore	SPRIGN TRIGGER	1	
17	323-47091	Leva acceleratore	TRIGGER	1	
18	323-47094	Carter destro	RIGHT COVER FOR HANDLE	1	
19	32-91327	Vite	SCREW	3	
20	32-90305	Vite	SCREW	1	
21	323-43023	Pomello	CLAMP KNOB	1	
ZC2	323-43013	Supporto manubrio superiore	handle upper/middle clamp assy	1	
ZC2-1	323-43014	Supporto manubrio inferiore compl.	handle Lower Clamp ASSY	1	
30	323-46580	Bretella doppia	BELT ASSY	1	
31	YD45-90022	Dado	SCREW	1	
31-1	YD25-92001	Bullone a brugola	SCREW	1	
32	32-46582	Blocco del gancio	SUPPORT HOOK	1	
33	32-46581	Gancio per tracolla	HOOK	1	
34	323-48116A	Fascetta	CLAMP	1	
35	32-90012	Vite	SCREW	2	
36	323-48118A	Passafilo	CLAMP	2	
37	26-48059	Fascetta parasassi superiore	protector upper plate	1	
38	43-48052	Fascetta parasassi inferiore	protector under plate	2	
40	323A-48054	Parasassi	PROTECTION COVER	1	
41	323A-48060	Protezione inferiore parasassi	PROTECTION COVER PAD	1	
42	323A-480562A	Coltello	small blade	1	
43	YD25-91323	Vite	SCREW	1	
44	323A-48061	Vite	SCREW	2	
ZC3	32-48040	Testina ingranaggi completa	GEAR BOX ASSY	1	
45	32-93214	Anello diam. 26	RINGΦ26	1	
46	321-93216	Anello diam. 10	RINGΦ10	1	
47	32-96017	Cuscinetto 6200RS	BALL BEARING	3	
48	32-48041	Pignone	INPUT BEVEL GEAR	1	
49	32-48042	Carter testina	GEAR BOX COVER	1	
50	321-90012	Vite	SCREW	1	
51	32-90308	Vite	SCREW	1	
52	32-48043	Corona	OUTPUT BEVEL GEAR	1	
53	32-96018	Cuscinetto 6002Z	BALL BEARING	1	
54	32-48044	Alberino	OUTPUT GEAR SHAFT	1	
55	YD38-93211	Anello diam. 32	RINGΦ32	1	
56	32-480452	Protezione	BLADE PLATE	1	
57	321-97303	Vite	SCREW	3	
58	YD45-90022	Vite	SCREW	1	
60	32-48046	Flangia superiore	UPPER GEAR BOX PLATE	1	
61	32-48047	Flangia inferiore	UNDER GEAR BOX PLATE	1	
62	32-48048	Coppetta dado	COVER BOARD	1	
63	321-92105	Dado	NUT	1	
ZC4	32-48180	Testina filo	Nylon head assy	1	
64	32-48233	Coperchio superiore	Nylon head cover	1	
65	32-48235	Molla	Return spring	1	
66	32-48185	Filo	Nylon rope	1	
67	32-48236	Rocchetto	shaft for line of spool	1	
68	32-48237	Boccola	Sheath of nylon head	2	
69	32-48238	Coperchio inferiore	Support for spool	1	



POS.NR	PART NR.	DESCRIZIONE	DESCRIPTION	Q.TY	REMARK
1	YD62-97004	Vite	SCREW	4	
2	433-18303	Protezione avviamento	FUEL TANK BRACKET	1	
3	32-25311	Manopola	STARTER HANDLE	1	
4	32-25301	Fune	ROPE-STARTER	1	
5	YD25-25318	Guarnizione manopola	WASHER-STARTER HANDLE	1	
6	323A-25302	Boccola passafilo	ROPE JACKET	1	
7	323A-251102	Carter avviamento	HOUSING START (EASY START)	1	
8	32-252122	Molla avviamento	START SPRING (EASY START)	1	
9	32-252112	Puleggia avviamento	START PULLEY (EASY START)	1	
10	323A-25112	Molla Easy start	START TORSIONAL SPRING	1	
11	323A-252152	Puleggia Easy start	SMALL START PULLEY	1	
12	YD25-93011	Rondella	WASHER-STARTER ASSY	1	
13	323A-25288	Vite	SCREW	1	
14	32-252602	Puleggia con cricco	PULLEY ASSY (EASY START)	1	
15	YD38-95012	Paraolio	SEAL OIL	1	
16	433-13201	Carter motore lato avv.to	LEFT CRANKCASE	1	
17	43-13090	Guarnizione cilindro	GASKET OF CRANKCASE	1	
18	YD25-96011	Cuscinetto	BEARING BALL	1	
19	43-14110	Albero motore	CRANKSHAFT ASSY	1	
20	43-96119	Gabbia a rulli	NEEDLE BEARING	1	
21	436-14210	Pistone	PISTON	1	
22	43-14001	Spinotto	PISTON PIN	1	
23	43-14002	Fermo spinotto	RING SNAP	2	
24	43-14311	Anello pistone	PISTON RING	2	
25	43-94602	Chiavetta	KEY FLYWHEEL	1	
26	43-96013	Cuscinetto	BEARING BALL	1	
27	YD62-94031	Spina	PIN	2	
28	43-13101	Carter motore lato volano	RIGHT CRANKCASE	1	
29	YD62-94031	Spina	SCREW	2	
30	43-95012	Paraolio	SEAL OIL	1	
31	LJ230B-97007	Spina	SCREW	4	
32	43-15110	Volano	FLYWHEEL ASSY	1	
33	YD25-92102	Dado	NUT	1	
34	32-93004	Rondella	WASHER	2	
36	32-22110F	Frizione completa	CLUTCH	1	
37	32-93402	Rondella	WASHER	2	
38	32-22133	Vite	SCREW	2	
39	431-26151	Cavo massa	WIRE	1	
40	43-26110	Bobina	ELECTRIC IGNITION ASSY	1	
41	LJ230B-97006	Vite	SCREW	2	
42	32-22121	Campana frizione	CLUTCH COVER	1	
43	32-93215	Anello diam. 36	RING ϕ 36	1	
44	32-96019	Cuscinetto	BALL BEARING	1	
45	32-93217	Anello diam. 15	RING ϕ 15	1	
46	436-443242	Carter volano	DRIVE SHAFT COVER	1	
47	321-97013	Vite	SCREW	4	
48	32-443232	Antivibrante	BUSH	1	
49	32-44327	Supporto asta	ALUMINUM TUBE FIXED SHELL	1	
50	321-90012	Vite	SCREW	1	
51	YD38-90024	Vite	SCREW	1	
52	YD38-93211	Anello diam. 32	RING ϕ 32	1	
53	325-16308	Pomello filtro aria	CHOKE KNOB	1	
54	436-16301	Coperchio filtro aria	COVER AIR FILTER	1	
55	436-16313	Elemento	SPONGE-AIR FILTER	1	
56	321-90033	Vite	SCREW	2	
57	43-16311	Piastra base filtro aria	CHOKE PLATE	1	
58	436-24009	Guarnizione	CHOKE GASKET	1	
59	326-24006	Leva aria	CHOKE	1	
61	323-16212	Boccola base filtro aria	BUSH-CHOKE	2	
62	436-16211	Base filtro aria	AIR FILTER BASE	1	
63	43-18200	Carburatore	CARBURATOR	1	

POS.NR	PART NR.	DESCRIZIONE	DESCRIPTION	Q.TY	REMARK
64	43-18204	Guarnizione carburatore	GASKET OF CARBURETOR	1	
65	YD62-97004	Vite	SCREW	2	
66	43-16111	Flangia termica	BOOT INTAKE	1	
67	43-16001	Guarnizione flangia term.	GASKET OF BOOT INTAKE	1	
68	323-26200	Candela	SPARK PLUG	1	
69	YD62-97004	Vite	SCREW	4	
70	436-12111	Cilindro	CYLINDER	1	
71	43-12501	Guarnizione cilindro	GASKET OF CYLINDER	1	
72	436-21003	Guarnizione marmitta	GASKET OF MUFFLER	1	
73	43-21110	Marmitta	MUFFLER	1	
74	YD62-97003	Vite	SCREW	1	
75	321-97010	Vite	SCREW	2	
76	436-26118	Coperchio candela	COVER SPARE PLUG	1	
77	YD525-90030	Vite	SCREW	1	
78	YD62-97003	Vite	SCREW	1	
79	436-11301	Coperchio cilindro	CYLINDER COVER	1	
84	32-18033	Guarnizione tappo	FUEL CAP	1	
87	32-181011	Tubo mix	FUEL HOSE	1	
88	32-181012	Tubo mix	FUEL HOSE	1	
89	32-18104	Gommino tubi mix	SUPPORT FUEL HOSE	1	
90	325-18109	Fascetta	SNAP- FUEL HOSE	1	
91	32-18034	Filtro mix	FUEL FILTER ASSY	1	
92	433-18306	Serbatoio	FUEL TANK	1	
93	323-18304	Gommino	DAMPING	4	
94	323-18305	Boccola	BUSH	4	
95	433-18213	Supporto serbatoio	FIXED BASE	1	
96	YD62-97004	Vite	SCREW	4	
ZC1	43-14000	Albero motore c/pistone	CRANKSHAFT WITH PISTON ASSY	1	
ZC2	32-25000	Avviamento completo	STARTER ASSY	1	
ZC3	32-18030	Tappo completo	FUEL CAP ASSY	1	
ZC4	43-18300	Serbatoio completo	FUEL TANK ASSY	1	
ZC5	436-44300	Carter volano completo	DRIVE OUTPUT ASSY	1	