



## Accessories





Model	Pos. Nr.	Part. Nr.	Descrizione	Description	Q.tà	Serial no.
WR147E.1	2	50035179	BULLONE	Bolt	5	
WR147E.1	3	50036864	AMMORTIZZATORE	Swinging foot	1	
WR147E.1	5	50020977	MAGNETE	Magnet	1	
WR147E.1	19	50040365	VITE C/RONDELLA M4x14	Screw Washer Assembly M4*14	3	
WR147E.1	20	50028034	MAGNETE	Magnet	1	
WR147E.1	23	50031651	VITE AUTOFIETTANTE	Self Tapping Screw	20	
WR147E.1	25	50044040	PELLICOLA TASTIERA	Keyboard film	1	
WR147E.1	26	50040734	COPERCHIETTO	Decorative Cover	1	
WR147E.1	29	50044047	SCHEDA DISPLAY	Display Circuit Board	1	
WR147E.1	30	50036842	LINGUETTA	Press plate	3	
WR147E.1	33	50032343	CLIP PLATE	Clip Plate	1	
WR147E.1	34	50044333	TERMINALE (NERO)	Terminal(Black)	1	
WR147E.1	36	50032541	MOLLA DI TORSIONE	Torsional Spring	2	
WR147E.1	39	50044332	TERMINALE (ROSSO)	Terminal(Red)	1	
WR147E.1	40	50032718	VITE	Screw	2	
WR147E.1	41	50044335	SCHEDA STAZIONE DI RICARICA	Power panel assembly	1	
WR147E.1	43	50044420	COPERCHIO TORRETTA	Guard	1	
WR147E.1	44	50043732	PIASTRA DI BASE	Base Plate	1	
WR147E.1	45	50041289	ALIMENTATORE(100-240V,20V,90W)	Charger(100-240V,20V,90W)WA3775	1	
WR147E.1	46	50043723	CAVO ALIMENTATORE	Cable Assembly	1	
WR147E.1	47	50026445	VITE PER FISSAGGIO BASE	Screw	8	
WR147E.1	48	50032396	SET LAME E VITI (3+3PZ)	Cutting blades and screws(3+3pcs)	1	
WR147E.1	49	50022577	VITE LAMA LANDROID	Screw	3	
WR147E.1	50	50040342	MATASSA CAVO PERIMETRO	Spool&Line (180m)	1	
WR147E.1	51	50032453	FERMACAVI	Cable clips	1	
WR147E.1	52	50002339	CHIAVE BRUGOLA 5	Spanner	1	
WR147E.1	53	50041423	SCHEDA MADRE LANDROID	Main Board	1	
WR147E.1	53	50045467	SCHEDA MADRE LANDROID	Main Board	1	
WR147E.1	54	50040730	GUARNIZIONE	Sealing Strip	1	
WR147E.1	58	50036879	SENSORE DI SOLLEVAMENTO	Lift sensor	2	
WR147E.1	59	50041134	SENSORE DI COLLISIONE	Control Board	1	
WR147E.1	61	50041374	COPERCHIO	Cover	1	
WR147E.1	62	50040717	CABLAGGIO SCHEDA ULTRASUONI	Ultrasonic Wire Harness	1	
WR147E.1	63	50036840	SENSORE PERIMETRO	Boundary sensor	1	
WR147E.1	65	50040743	GUARNIZIONE	Sealing Strip	1	
WR147E.1	66	50040741	SENSORE PIOGGIA	Rain Wire Harness	1	
WR147E.1	67	50040720	SENSORE	Detection Plate	1	
WR147E.1	68	50040711	GUARNIZIONE	Sealing Strip	1	
WR147E.1	69	50040718	IMPUGNATURA	Handle	1	
WR147E.1	70	50036905	PRESA USB	Control Board	1	
WR147E.1	73	50044044	COLLEGAMENTO	Valve houseing	1	
WR147E.1	75	50040723	MOLLA DI COMPRESSIONE	Compression Spring	1	
WR147E.1	77	50036907	SUPPORTO BATTERIA	Base Holder	1	
WR147E.1	78	50040738	VITE AUTOFIETTANTE	Self Tapping Screw	8	
WR147E.1	80	50037221	GOMMINO	Cushion	1	
WR147E.1	81	50036851	VITE AUTOFIL. ST4.8x20	Self tapping screw ST4.8*20	24	
WR147E.1	82	50037157	O RING	O Ring	1	
WR147E.1	83	50037158	COPERCHIO MODULO GPS	Cover	1	
WR147E.1	96	50037163	BATTERIA LITIO 4.0AH 20V(WA3553.3)	Battery pack(Li-ion,4.0Ah,20V) WA3553.3	1	
WR147E.1	97	50040413	GUARNIZIONE	Airproof Ring	2	
WR147E.1	98	50041466	MOTORE RUOTA COMPLETO	Gear Case Set	2	
WR147E.1	99	50040706	COPERCHIO RIDUTTORE SIN.	Gear Box Cover Assembly	1	
WR147E.1	100	50041369	RUOTA POSTERIORE DESTRA	Right Rear Wheel	1	
WR147E.1	102	50028148	RONDELLA ELASTICA	Spring Washer	2	
WR147E.1	103	50028149	DADO	Nut	2	
WR147E.1	104	50041366	COPERCHIO RUOTA	Roller Guard Assembly	2	
WR147E.1	105	50040707	COPERCHIO RIDUTTORE DES.	Gear Box Cover Assembly	1	

Model	Pos. Nr.	Part. Nr.	Descrizione	Description	Q.tà	Serial no.
WR147E.1	106	50041467	MANOPOLA REGOLAZ. ALTEZZA	Height Adjustment Knob	1	
WR147E.1	107	50040658	MOLLA DI COMPRESSIONE	Compression Spring	1	
WR147E.1	108	50040659	VITE DI REGOLAZIONE	Adjustment Screw	1	
WR147E.1	111	50040662	PERNO A MOLLA	Spring Pin	4	
WR147E.1	113	50037042	MOLLA	Extension Spring	2	
WR147E.1	114	50041468	SUPPORTO 2	Link2	1	
WR147E.1	115	50040660	BASE DI APPOGGIO	Support Base	1	
WR147E.1	116	50044098	PROTEZIONE DISCO LAME	Guard Assembly	1	
WR147E.1	118	50040379	DISCO PORTA LAME	Adapter Ring	1	
WR147E.1	119	50040740	CAVO	Cable	1	
WR147E.1	120	50040705	CABLAGGIO SENSORE PIOGGIA	Rain Wire Harness	1	
WR147E.1	121	50040726	CABLAGGIO SENSORE PERIMETRO	Border Wire Harness	1	
WR147E.1	122	50040721	CABLAGGIO ACCESSORI	Can Bus	1	
WR147E.1	124	50042456	CARTER PRINCIPALE	Base Assembly	1	
WR147E.1	125	50040714	CAVO	Cable	1	
WR147E.1	126	50040737	CABLAGGIO SENSORE DI COLLISION	Collision Sensing Wire Harness	1	
WR147E.1	127	50041081	CABLAGGIO SCHEDA DISPLAY	Transfer Plate Wiring Harness	1	
WR147E.1	128	50041469	SUPPORTO 1	Link1	1	
WR147E.1	132	50041373	RUOTA POSTERIORE SINISTRA	Left Rear Wheel	1	
WR147E.1	133	50028147	RONDELLA	Washer	2	
WR147E.1	134	50041370	SUPPORTO	Bracket	1	
WR147E.1	135	50041367	COPERCHIO	Cover	1	
WR147E.1	136	50041372	SUPPORTO	Bracket	1	
WR147E.1	137	50040725	COPERCHIO	Cover	2	
WR147E.1	138	50042457	MOLLA	Spring	2	
WR147E.1	142	50023010	RONDELLA GRANDE	Big washer	1	
WR147E.1	201	50044028	CONTATTI PER RICARICA	Charging harness	1	
WR147E.1	202	50040411	SET RUOTE ANTERIORI	Front Wheel Set	2	
WR147E.1	205	50040710	CONNETTORE BATTERIA	Power Wire Harnes	1	
WR147E.1	206	50041516	COPERCHIO	Cover	1	
WR147E.1	207	50040651	COPERTURA DEL MOTORE	Motor Cover	1	
WR147E.1	208	50044334	SUPPORTO BASE	Base Holder	1	
WR147E.1	209	50044423	TORRETTA STAZIONE DI RICARICA	Charge station assembly(w/o base)	1	
WR147E.1	301	50040708	COFANO	Cover	1	
WR147E.1	302	50044592	CARTER SUPERIORE	Top Cover Assembly	1	
WR147E.1	303	50040739	GRUPPO MOTORE LAME	Aadjust Height Assembly	1	
WR147E.1	304	50002909	VITE AUTOFILETTANTE	Screw	9	
WR147E.1	305	50040709	GUARNIZIONE	Sealing Strip	1	
WR147E.1	306	50041470	TAPPO	valve houseing	1	
WR147E.1	308	50044037	MANOPOLA DI REGOLAZIONE	Adjusting knob	1	