














Accessories



205



wiring diagram



Model	Model	Pos. Nr.	Part. Nr.	Descrizione	Description	Q.tà	Serial no.
WR155E	WR155E	1	50036918	ETICHETTA	Rated Label	1	
WR155E	WR155E	2	50037161	MUSETTO **	Top Cover2 Assembly	1	
WR155E	WR155E	3	50022550	VITE	Screw	3	
WR155E	WR155E	5	50031651	VITE AUTOFIETTANTE	Self Tapping Screw	12	
WR155E	WR155E	6	50036864	AMMORTIZZATORE	Swinging foot	3	
WR155E	WR155E	7	50037149	VITE AUTOFIL 2.9X6	Self Tapping Screw2.9X6	2	
WR155E	WR155E	8	50020977	MAGNETE	Magnet	2	
WR155E	WR155E	10	50037031	SUPPORTO	Damping Block	1	
WR155E	WR155E	12	50036908	MOLLA TORSIONALE	Torsional Spring	1	
WR155E	WR155E	13	50037032	PERNO DELLO SPORTELLLO	Output Spindle	1	
WR155E	WR155E	14	50036839	COPERCHIO SENSORE ULTRAS.	Ultrasonic cover plate	1	
WR155E	WR155E	15	50035179	BULLONE	Bolt	5	
WR155E	WR155E	17	50036850	TASTIERA/DISPLAY	Press button	1	
WR155E	WR155E	20	50037025	BASE CHIUSURA MAGNETE	Washer	2	
WR155E	WR155E	21	50016106	VITE AUTOFIETTANTE	self tapping screw	2	
WR155E	WR155E	22	50037154	GUARNIZIONE	Sealing Strip	1	
WR155E	WR155E	23	50037022	PIASTRINA	Decorative Cover	1	
WR155E	WR155E	25	50036895	GUARNIZIONE	Seal foam for Sound inlet	1	
WR155E	WR155E	26	50037028	GANCIO	Linkage	1	
WR155E	WR155E	27	50037027	PULSANTE STOP	Button Set	1	
WR155E	WR155E	28	50037030	MAGNETE	Magnet	2	
WR155E	WR155E	29	50036878	GUARNIZIONE DI TENUTA (STOP)	Seal sleeve(STOP)	1	<201930198610000155
WR155E	WR155E	29	50026060	GOMMINO INTERRUTTORE	Sheath II	1	>=201930198610000155
WR155E	WR155E	30	50018399	RONDELLA	Washer	1	<201930198610000155
WR155E	WR155E	31	50040504	INTERRUTTORE	Switch	1	>=201930198610000155
WR155E	WR155E	31	50036880	INTERRUTTORE	Switch	1	<201930198610000155
WR155E	WR155E	32	50000976	RONDELLA	Washer	2	<201930198610000155
WR155E	WR155E	33	50040502	DISPLAY CIRCUITO STAMPATO	Display Circuit Board	1	>=201930198610000155
WR155E	WR155E	33	50036859	DISPLAY	Display Circuit Board	1	<201930198610000155
WR155E	WR155E	34	50036842	LINGUETTA	Press plate	2	
WR155E	WR155E	35	50002909	SELF TAPPING SCREW	Screw	2	
WR155E	WR155E	36	50034397	FERMAGLIO	Wire clip	3	
WR155E	WR155E	37	50036848	SENSORE DI COLLISIONE	Collision sensor	1	
WR155E	WR155E	38	50037055	PORTA BATTERIA	Battery pack interface assembly	1	
WR155E	WR155E	39	50026099	GOMMINO	Rubber Pin	2	
WR155E	WR155E	40	50031776	BATTERIA LITIO 5.0AH 20V *	Battery Pack(Li-ion,5.0Ah,20V) WA3556	1	
WR155E	WR155E	41	50036862	SEDE BATTERIA	Supporting seat	1	
WR155E	WR155E	44	50036879	SENSORE DI SOLLEVAMENTO	Lift sensor	2	
WR155E	WR155E	45	50036858	COPERCHIO FINALE	End Cover	2	<201930198610000155
WR155E	WR155E	45	50040167	COPRIMOZZO RUOTA ANTERIORE	Front wheel end cover	2	>=201930198610000155
WR155E	WR155E	46	50028034	MAGNETE	Magnet	2	
WR155E	WR155E	47	50032327	MAGNET	Magnet	1	
WR155E	WR155E	48	50023969	RONDELLA	Retaining Ring	2	
WR155E	WR155E	50	50036840	SENSORE PERIMETRO	Boundary sensor	1	
WR155E	WR155E	51	50032535	PARAOLIO	Oil Seal Bearing	2	
WR155E	WR155E	52	50041438	RONDELLA	Washer	4	
WR155E	WR155E	53	50036866	RUOTA ANTERIORE PIVOTTANTE	Front Wheel Assembly	2	
WR155E	WR155E	54	50023797	O-RING	O Rings	1	
WR155E	WR155E	55	50037038	COPERCHIO	Cover	1	
WR155E	WR155E	57	50037221	GOMMINO	Cushion	1	
WR155E	WR155E	59	50036868	CABLAGGIO SENSORE ULTRASUONI	Ultrasonic wire harness	1	
WR155E	WR155E	60	50045467	SCHEDA MADRE LANDROID ***	Main Board	1	
WR155E	WR155E	61	50036852	COPERCHIO	Cover	1	
WR155E	WR155E	62	50036851	VITE AUTOFIL. ST4.8 x 20	Self tapping screw ST4.8*20	18	
WR155E	WR155E	64	50036905	PRESA USB	Control Board	1	
WR155E	WR155E	65	50037546	COPRI RUOTA	Roller Guard	2	>=201930198610000547
WR155E	WR155E	65	50036845	COPERCHIO RUOTA POSTERIORE	Roller Guard	2	<201930198610000547
WR155E	WR155E	66	50028149	DADO	Nut	2	
WR155E	WR155E	67	50028148	RONDELLA ELASTICA	Spring Washer	2	
WR155E	WR155E	68	50028147	RONDELLA	Washer	2	
WR155E	WR155E	69	50040742	RUOTA POSTERIORE	Rear Wheel	2	>=201930198610000547
WR155E	WR155E	69	50036846	RUOTA POSTERIORE	Rear Wheel	2	<201930198610000547
WR155E	WR155E	70	50036874	MOTORE RUOTA	Driving motor set	2	
WR155E	WR155E	71	50022545	O-RING	O Ring	2	
WR155E	WR155E	72	50036861	MANOPOLA REGOLAZIONE ALTEZZA	Height Adjustment Knob	1	
WR155E	WR155E	77	50037798	MOLLA DI COMPRESSIONE	Compression Spring	4	
WR155E	WR155E	78	50036869	RASTRELLO	Guard	1	
WR155E	WR155E	79	50024711	RONDELLA BLOCCO PIATTO LAME	Spacer	1	

Model	Model	Pos. Nr.	Part. Nr.	Descrizione	Description	Q.tà	Serial no.
WR155E	WR155E	80	50022575	VITE AUTOFILETTANTE	Screw Washer	3	
WR155E	WR155E	83	50037232	DISCO PORTACOLTELLI	Turning disc	1	
WR155E	WR155E	84	50026445	VITE PER FISSAGGIO BASE *	Screw	8	
WR155E	WR155E	85	50029530	MATASSA CAVO PERIMETRO	Boundary wire (250m)	1	
WR155E	WR155E	86	50036882	SET PICCHETTI (340 PZ)	Clip(Hook 340)	1	
WR155E	WR155E	88	50002339	CHIAVE BRUGOLA 5	Spanner	1	
WR155E	WR155E	89	50032719	CONNETTORE CAVO PERIMETRO *	Boundary wire connecter	2	
WR155E	WR155E	90	50036872	CABLAGGIO ELETTRICO (STOP)	Stop Wiring harness	1	<201930198610000155
WR155E	WR155E	91	50036847	CABLAGGIO SENSORE DI COLLISION	Collision sensing wire harness	1	
WR155E	WR155E	92	50036873	CABLAGGIO SCHEDA DISPLAY	Transfer plate Wiring harness	1	
WR155E	WR155E	93	50036856	CABLAGGIO ELETTRICO (ACCESSOR)	Can Bus	1	
WR155E	WR155E	94	50036853	CABLAGGIO SENSORE PERIMETRO	Border wire harness	1	
WR155E	WR155E	95	50036988	CABLAGGIO SENSORE PIOGGIA	Rain wire harness	1	
WR155E	WR155E	96	50036843	CABLAGGIO MOTORE	Cut motor connection Wire harness	1	
WR155E	WR155E	97	50034566	TERMINALE CON FILO NERO	Terminal with black wire	1	
WR155E	WR155E	98	50034565	TERMINALE CON FILO ROSSO	Terminal with red wire	1	
WR155E	WR155E	101	50032541	MOLLA DI TORSIONE	Torsional Spring	2	
WR155E	WR155E	102	50032343	COPERCHIO IN PLASTICA	Clip Plate	1	
WR155E	WR155E	103	50034259	TORRETTA RICARICA	Base Holder	1	<201930198610000155
WR155E	WR155E	103	50040107	TORRETTA DI RICARICA	Base Holder	1	
WR155E	WR155E	104	50032718	VITE	Screw	8	
WR155E	WR155E	105	50032352	SWITCH BOX	Switch Box	1	
WR155E	WR155E	107	50037741	SCHEDA STAZIONE DI RICARICA	Power panel assembly	1	
WR155E	WR155E	108	50034255	COPERCHIO TORRETTA	Ornament Cover	1	
WR155E	WR155E	109	50036841	PIASTRA DI BASE	Base Plate	1	
WR155E	WR155E	110	50045646	ALIMENTATORE(100-240V,20V,90W)	Charger(100-240V,20V,90W)WA3776	1	
WR155E	WR155E	110	50041289	ALIMENTATORE(100-240V,20V,90W) Shuko	Charger(100-240V,20V,90W)WA3775 Shuko	1	
WR155E	WR155E	111	50035691	CAVO ALIMENTATORE 10MT	Cable Assembly	1	
WR155E	WR155E	112	50036844	MANICOTTO PER CAVI	Cable Sleeve	1	
WR155E	WR155E	113	50037036	SPUGNA	Sponge	2	
WR155E	WR155E	117	50040503	RONDELLA	Washer	2	>=201930198610000155
WR155E	WR155E	201	50037160	AMMORTIZZATORE	Swinging foot Set	3	
WR155E	WR155E	202	50036887	CABLAGGIO BATTERIA	Power wire harness	1	
WR155E	WR155E	203	50037162	SCOCCA PRINCIPALE	Base Set	1	<201930198603000706
WR155E	WR155E	203	50039194	SCOCCA PRINCIPALE	Base Set	1	
WR155E	WR155E	203	50042489	SCOCCA PRINCIPALE	Base Set	1	>=201930198610000155
WR155E	WR155E	204	50037223	SET MOTORE	Motor set	1	
WR155E	WR155E	205	50037227	STAZIONE DI RICARICA	Charge station assembly	1	
WR155E	WR155E	206	50032396	SET LAME E VITI (3+3PZ)	Cutting blades and screws(3+3pcs)	1	
WR155E	WR155E	207	50037220	COFANO PRINCIPALE	Top Cover Base Assembly	1	<201930198603000706
WR155E	WR155E	207	50039193	COFANO PRINCIPALE	Top Cover Assembly	1	
WR155E	WR155E	207	50043006	COFANO PRINCIPALE	Top Cover Assembly	1	>=201930198610000155
WR155E	WR155E	207	50043006	COFANO PRINCIPALE	Top Cover Assembly	1	